

Kaymar

Fitting Instructions

Vehicle	GQ Patrol
Year	
Type	Wagon
Part	Rear Bar

Applicable to Part Numbers

K2610, KITGQ, KITGQ-R-JCS, KITGQ-R-JCD

Date published December 20, 2016

IMPORTANT - BEFORE COMMENCING INSTALLATION

Please verify the part number corresponds with the list above.
Read through these instructions and check items in the supplied fitting kit matches the attached list.

Every effort is made to ensure instructions are as accurate as possible at the time of publishing however work should not be commenced until the document has been thoroughly read, measurements checked and all components in the package verified as complete. Kaymar has used reasonable care in preparing the information included in these documents, but makes no representations or warranties as to the completeness or accuracy of the information. Information is supplied upon the condition that the persons receiving the information will make their own determination as to its suitability for their purposes prior to use. Kaymar assumes no liability whatsoever for any damages incurred by you resulting from errors in or omissions from the information included herein. Kaymar reserves the right to make changes without further notice to any products to improve reliability, function or design.

NISSAN GQ

1. Remove original bar and all mounting brackets, taking note of the position of the original bolts.
2. Remove the chequer plate from the Kaymar bar.
3. Lift bar onto vehicle and fit original bolts into original holes.
4. DO NOT TIGHTEN ANY BOLTS.
5. Slide the bolts with wires into the chassis rail and fit these through the hole corresponding with the extension arm on the bar. The square washers fit in between the chassis and the bar arms.
6. Make sure the bar sits square and parallel on the car.
7. TIGHTEN AKK BOLTS.
8. Fit the chequer plate top.

Kaymar 4WD Accessories
DRIVEN BY INNOVATION, GUIDED BY EXPERIENCE.

90 Beresford Road, Lilydale, Vic, 3140, Australia
www.kaymar.com.au sales@kaymar.com.au P: +61 3 9739 4110 F: +61 3 9739 4111




BK2610 GQ REAR BAR

QUANTITY	DESCRIPTION
2	BOLT ON WIRE M16 x 45 X 1.5 300 MM WIRE
2	NUT M16 X 1.5
2	WASHER FLAT M16 HD
2	WASHER SPRING M16
2	PACKER 5MM 50 X 50



bolt_on_wire_M16x45x1.5_300mm_wire



packer_5mm_50x50

Date published December 20, 2016