

# Kaymar

## Fitting Instructions



Suitable for

**Ford Everest**

Year **Hands Free Tailgate**

Type **Wagon**

Part

**Applicable to Part Numbers**

**K6101**

**See also related fitting instructions for reversing sensors, carriers and jerry can holders**

Date published June 24, 2020

### **IMPORTANT - BEFORE COMMENCING INSTALLATION**

**Please verify the part number corresponds with the list above. Read through these instructions and check items in the supplied fitting kit matches the attached list.**

**Ford Everest Tailgate Hands Free Sensor Bracket  
K6101  
(Sold Separately)**

# Kaymar

## Fitting Instructions



### Ford Everest Tailgate Hands Free Sensor Bracket K6101

1. Locate the 20mm hole in the chassis approx 230mm from the outside wall of the the tow hitch receiver on the passenger side.



2. Hold the bracket against the chassis using the 20mm washer welded to the bracket as a guide.
3. Fit the first M8 x 20 bolt on wire on through the chassis and bring out through the washer. Secure using M8 spring washer and M8 Nyloc nut.



4. Fit the second bolt on wire through the same hole in the chassis up to the remaining hole in the bracket. Secure using M8 spring washer and M8 Nyloc nut.



5. Fit sensor to the bracket using 3/16 screws provided.
6. Cut off any excess wire from the bolts on wire.



Tailgate Hands Free Sensor Bracket Kit