

Kaymar

Fitting Instructions

Vehicle Ranger PX Reversing Camera Relocation

Year Post 2012

Type Ute

Part Rear Bar

Date published December 12, 2018

IMPORTANT - BEFORE COMMENCING INSTALLATION

Please verify the part number corresponds with the list above.

Read through these instructions and check items in the supplied fitting kit matches the attached list.

Every effort is made to ensure instructions are as accurate as possible at the time of publishing however work should not be commenced until the document has been thoroughly read, measurements checked and all components in the package verified as complete. Kaymar has used reasonable care in preparing the information included in these documents, but makes no representations or warranties as to the completeness or accuracy of the information. Information is supplied upon the condition that the persons receiving the information will make their own determination as to its suitability for their purposes prior to use. Kaymar assumes no liability whatsoever for any damages incurred by you resulting from errors in or omissions from the information included herein. Kaymar reserves the right to make changes without further notice to any products to improve reliability, function or design.

FORD RANGER PX CAMERA

1. Unplug camera harness from underneath the right side of the vehicle.



2. Open the tailgate and remove the panel by removing all screws.
Set aside for later use.



Kaymar

Fitting Instructions

3. Remove the two grommets. One in the body and the other in the bottom of the tailgate. Unclip the harness and pull through from under the body.



4. Unclip the Ford badge from the chrome housing on the tailgate.
Undo the two screws and remove the chrome housing.
Undo the screw holding the retaining bracket and remove the camera.



5. Knock out the blanking washer in the centre of the bar above the tow hitch receiver.
Touch up with rust proof paint.



Kaymar

Fitting Instructions

6. Note which way the camera is up and fit to the bracket on the inside of the bar.
Using the retaining bracket provided secure using the 6mm button head screws, fix to the bar.
7. Discard the grommets from the camera harness and cover the wiring in conduit.
Plug the harness back into the camera and to original plug under the tub.



8. Refit the Ford badge and chrome surround.
Using the rubber grommet supplied push into the hole where the camera was removed.



Fitting Kit

- 1 x Rubber grommet CBG7
- 1 x PX retainer bracket K580E
- 2 x M6 x 20 hex head screws