

## Toyota FJ CRUISER CAMERA KIT Fitting Instructions

1. Remove two x screws from top of door trim.  
Open tail gate hatch, then gently pull trim away from door.  
Remove trim.
2. Peel back plastic dust cover and pull original camera loom back through tail gate.



3. Plug in short camera loom into original plug



4. Remove jack from storage area, and make a small cut in either end of original rubber conduit. Feed camera loom through as per photo.



5. Remove rubber grommet from under left side of vehicle.
6. Remove plastic grommet from inside jack storage area. Make a small cut in both grommets, then feed camera loom through. Fill cut in grommets with silicon.



7. Fit 30mm grommet supplied into hole in door.



8. Re-fit door trim using original hardware.
9. Run the camera loom up between tread plate and plastic bumper, along bottom of carrier arm using cable tie mounts.
10. If a carrier is being fitted. Run camera loom along bottom of carrier arm, and cable tie to cable tie mounts supplied.
11. Bolt black camera bracket to bottom of carrier arm using two M8 x 20 bolts, M8 spring and flat washer.
12. Fit camera to bracket using M6 pan head screw and M6 wizz nut.
13. Plug in camera.

