

# Kaymar

## Fitting Instructions



Suitable for

**Toyota Fortuner**

Year **Crusade**

Type **Wagon**

Part **Bump Stop**

**Applicable to Part Numbers**

**K6163**

See also related fitting instructions for reversing sensors, carriers and jerry can holders

Date published July 8, 2020

### **IMPORTANT - BEFORE COMMENCING INSTALLATION**

**Please verify the part number corresponds with the list above. Read through these instructions and check items in the supplied fitting kit matches the attached list.**

Please Note:

**This accessory is sold separately**

K6163 Bump Stop for carriers fitted to Crusade models with remote opening tailgate feature

# Kaymar

## Fitting Instructions



If fitting a carrier to a **Crusade** model it is advised to use a bump stop on the rear of the carrier arm to minimise potential for damage to the tail gate should the electric door opening be accidentally activated.

1. Hold the rubber stop against forward facing wall of the carrier arm, flush with the top and approximately 10mm in from the end of the carrier arm.
2. Mark the centre of the hole and drill out to 11mm.



3. Remove the end cap and fit the bump stop using M10 x 1.5 x 30 bolt, spring and flat washers and wizz nut.



4. Refit the end cap.



# Kaymar

## Fitting Instructions



### K6163 Bump Stop for Fortuner Crusade with remote opening tailgate feature

#### Bump Stop Kit for Crusade

- 1 BUMP STOP
- 1 M10 X 1.5 X 30 BOLT
- 1 M10 FLAT WASHER
- 1 M10 SPRING WASHER
- 1 M10 WIZZ NUT



*Fortuner\_bump\_stop\_kit\_Crusade*