

Kaymar

Fitting Instructions



Vehicle Patrol GU
Year Pre Oct 2004
Type Wagon
Part Rear Bar

Applicable to Part Numbers

K3530, KITGU-LIB, KITGU-LIB-R-JCD

Date published December 7, 2016

IMPORTANT - BEFORE COMMENCING INSTALLATION

Please verify the part number corresponds with the list above.

Read through these instructions and check items in the supplied fitting kit matches the attached list.

Every effort is made to ensure instructions are as accurate as possible at the time of publishing however work should not be commenced until the document has been thoroughly read, measurements checked and all components in the package verified as complete. Kaymar has used reasonable care in preparing the information included in these documents, but makes no representations or warranties as to the completeness or accuracy of the information. Information is supplied upon the condition that the persons receiving the information will make their own determination as to its suitability for their purposes prior to use. Kaymar assumes no liability whatsoever for any damages incurred by you resulting from errors in or omissions from the information included herein. Kaymar reserves the right to make changes without further notice to any products to improve reliability, function or design.

NISSAN GU PRE 10/04

NOTE: Glue rubber strips on first.

1. Remove original rear bumper and towbar (If fitted)
2. Make sure the sides of the chassis rails and the large tie down lug welded to it are straight up and down. On most vehicles these areas are flared out. They must be straight and square to allow the bar to slip on.
3. Fit the chassis insert plates with two 12mm X 35 bolts welded to them, inside each chassis rail. Do not drop the bolts into the holes.



Kaymar

Fitting Instructions

4. Undo the exhaust bracket closest to the rear of the vehicle to allow the exhaust to hang freely.
5. Fit the bar onto the chassis slowly and evenly taking care not to hit the side wings against the body.
6. Fit the four 14mm bolts and washers through the chassis side plates first. **DO NOT TIGHTEN.**
7. Fit the bolts on the chassis insert plates down through the towbar arms. **DO NOT TIGHTEN.**



8. Fit the four M12 fine thread bolts into the original holes in the middle of the chassis. **DO NOT TIGHTEN.**
9. Tighten all bolts evenly making sure that the mounting surfaces on the bar sit flat against the chassis.
10. Drill through the chassis holes in the middle underneath of the rear cross member with a 12mm drill, using the holes in the rear bar mounting plate as a guide. Fit the two 12mm X 35 bolts on wires, washers and nuts.



11. Make sure all bolts are tight.
12. Wire up LED lights using wiring diagram, for reverse you will need to splice wire in behind L/H side tail light. Feed wire down through body and out through rubber grommet. Splice in another wire for R/H side.



Kaymar

Fitting Instructions

Left Hand Side

Reverse - Red/Blue - Black

Tail - Blue/Black - Brown

Stop - Thick Green/Yellow - Red

Indicator - Thin Green/Yellow - Yellow

Earth - Black - White

Right Hand Side

Reverse - from LHS - Black

Tail - Blue/Black - Brown

Stop - Green/Yellow - Red

Indicator - Green/Red - Yellow

Earth - Black - White

13. Align the original mudflaps and plastic backing plates with the ends of the bar wings, drill through the plate in the end of the wing and fit mudflaps using original hardware.
14. Apply a thin bead of silicone along the top of the bar and fit the chequer plate and plastic strip using the 6mm coach bolts supplied..
15. Re-fit the exhaust bracket. Some vehicles may need spacer washers to lower the pipe to miss the bar brace.

Kaymar

Fitting Instructions

BK3530 GU SERIES 1 PRE 04 REAR BAR

QUANTITY	DESCRIPTION
----------	-------------

4	BOLT M14 x 35 x 1.5
---	---------------------

4	WASHER FLAT M14 X 32 HD
---	-------------------------

4	WASHER SPRING M14
---	-------------------

2	BOLTS ON PLATE - 2 X M12 X 40 X 1.75
---	--------------------------------------

4	BOLT M12 X 35 X 1.25 FINE THREAD
---	----------------------------------

2	BOLT ON WIRE M12 X 30 X 1.75 150 MM WIRE
---	--

10	WASHER FLAT M12 X 30 HD
----	-------------------------

10	WASHER SPRING M12
----	-------------------

6	NUT M12 X 1.75
---	----------------

2	PACKER 5MM 270 X 43 GU
---	------------------------

2	PACKER 3MM 270 X 43 GU
---	------------------------

2	WING RUBBER - SMALL VEHICLE
---	-----------------------------




bolts_on_plate_2x_M12x40x1.75



bolt_on_wire_M12x30x1.75_150mm_wire



spacer_5mm_GU



spacer_3mm_GU



wing_rubber_small_vehicle