

Kaymar

Fitting Instructions



Vehicle **General**

Year

Type

Part **Lock Tab Washer**

Applicable to Part Numbers

Lock Tab Washers for Carriers

Date published November 16, 2016

IMPORTANT - BEFORE COMMENCING INSTALLATION

Please verify the part number corresponds with the list above.

Read through these instructions and check items in the supplied fitting kit matches the attached list.

Every effort is made to ensure instructions are as accurate as possible at the time of publishing however work should not be commenced until the document has been thoroughly read, measurements checked and all components in the package verified as complete. Kaymar has used reasonable care in preparing the information included in these documents, but makes no representations or warranties as to the completeness or accuracy of the information. Information is supplied upon the condition that the persons receiving the information will make their own determination as to its suitability for their purposes prior to use. Kaymar assumes no liability whatsoever for any damages incurred by you resulting from errors in or omissions from the information included herein. Kaymar reserves the right to make changes without further notice to any products to improve reliability, function or design.

LOCK TAB WASHER

1. Fit the top slide (wheel holder) into the wheel carrier.
2. Fit spring washer and small lock tab washer onto 16mm bolts.
3. Fit large 5mm thick washer onto bolt with lug (A) facing away from the head of the bolt.
4. Apply a thin film of grease to the bolts.
5. Screw 16mm bolt through the slots in the wheel carrier housing into the top slide. Make sure that the lug (A) fits into the slot first. Make sure you fit both bolts.
6. Fit the wheel and wheel lock plate.
7. Open the wheel carrier and stand behind it. **PULL THE TYRE INTO THE CARRIER FRAME SO THAT THE TYRE SITS HARD AGAINST THE FRAME.**
8. Tighten the two 16mm bolt to at least 140nm, make sure tab (B) fits into the cut-out in the 5mm washer.
9. Continue turning the bolt unit one flat on the hexagon is aligned with tab (C) of the lock tab washer.

Kaymar

Fitting Instructions



10. Flatten tab (C) onto a flat of the hexagon on the bolt head. Do the same with bolt bolts. Make sure the whole tab sits flat on the bolt head.

THIS MUST BE DONE

