

Kaymar

Fitting Instructions



Vehicle Navara D40
Year
Type Ute
Part Rear Bar

Applicable to Part Numbers

K2105U, KITD40U-L-JCS

Date published December 7, 2016

IMPORTANT - BEFORE COMMENCING INSTALLATION

Please verify the part number corresponds with the list above.

Read through these instructions and check items in the supplied fitting kit matches the attached list.

Every effort is made to ensure instructions are as accurate as possible at the time of publishing however work should not be commenced until the document has been thoroughly read, measurements checked and all components in the package verified as complete. Kaymar has used reasonable care in preparing the information included in these documents, but makes no representations or warranties as to the completeness or accuracy of the information. Information is supplied upon the condition that the persons receiving the information will make their own determination as to its suitability for their purposes prior to use. Kaymar assumes no liability whatsoever for any damages incurred by you resulting from errors in or omissions from the information included herein. Kaymar reserves the right to make changes without further notice to any products to improve reliability, function or design.

NAVARA D40

1. Remove original bumper and tow bar (if fitted).

*****Please check tub is square on the chassis and re-align if necessary before fitting Kaymar bar*****

2. Hammer metal tab on each chassis side so it is flat against chassis.
3. Slide bar onto chassis being careful not to touch the body corner of the vehicle.
4. Loosely fit the six M12 bolts to the underside of the chassis.
5. Fit the M14 bolts through the sides of the chassis.
6. Tighten M12 bolts first then M14 bolts.

Kaymar

Fitting Instructions

7. Splice into vehicle wiring before the plug above the left hand chassis rail for bar lights and trailer plug wiring.

VEHICLE:

Green/Silver - Right turn signal

Green/Silver - Left turn signal

(You will need a test light to determine which is left and right)

Grey/Silver - Tail light

Yellow - Stop

Black - Earth

Light Blue/Silver - Reverse

8. Fit chequer plate and plastic trim strip using M6 coach bolts. Run a thin bead of silicon across the top of the bar first.
9. See separate fitting sheet for wheel carriers if they are to be fitted.

Kaymar

Fitting Instructions

BK2105U NAVARA D40 REAR BAR

QUANTITY	DESCRIPTION
6	BOLT M12 X 35 X 1.25 FINE THREAD
6	BOLT M14 x 35 x 1.5
6	WASHER FLAT M12 X 30 HD
6	WASHER SPRING M12
6	WASHER FLAT M14 X 32 HD
6	WASHER SPRING M14