

Kaymar

Fitting Instructions



Vehicle Triton ML
Year
Type Ute
Part Rear Bar

Applicable to Part Numbers

K3800, KITRML-L-JCS

Date published December 1, 2016

IMPORTANT - BEFORE COMMENCING INSTALLATION

Please verify the part number corresponds with the list above.

Read through these instructions and check items in the supplied fitting kit matches the attached list.

Every effort is made to ensure instructions are as accurate as possible at the time of publishing however work should not be commenced until the document has been thoroughly read, measurements checked and all components in the package verified as complete. Kaymar has used reasonable care in preparing the information included in these documents, but makes no representations or warranties as to the completeness or accuracy of the information. Information is supplied upon the condition that the persons receiving the information will make their own determination as to its suitability for their purposes prior to use. Kaymar assumes no liability whatsoever for any damages incurred by you resulting from errors in or omissions from the information included herein. Kaymar reserves the right to make changes without further notice to any products to improve reliability, function or design.

MITSUBISHI TRITON ML

1. *****Please check tub is square on the chassis and re-align if necessary before fitting Kaymar bar*****
2. Remove original bar and towbar if fitted.
3. With another person, lift Kaymar bar onto vehicle being careful not to touch the body. Fit 6 x M12 x 35 x 1.75 bolt (3 either side) through from inside of chassis using flat, spring and nut. **DO NOT TIGHTEN.**
4. Fit M12 bolt on wire through inside of chassis to front most hole using M12 flat, spring and nut.
5. Fit remaining M12 x 35 x 1.75 bolt down through chassis and bar support brace, using M12 flat, spring and nut.
Tighten these 2 bolts first, then all side bolts.
6. Splice in light and trailer plug wiring as per the following instructions.

Kaymar

Fitting Instructions



7.	Vehicle	LED	
	RH Indicator	green/brown	yellow
	LH Indicator	green/yellow	yellow
	Stop	blue/orange	red
	Tail	green/orange	brown
	Reverse	red/green	black
	Earth	black/silver	white

Connect lights using terminals provided (Check all lights)

8. Run a bead of silicon along under side of chequer plate. Place plastic strip on silicon. Lining up the holes. Run another bead of silicon on plastic strip and screw chequer plate to bar, using M6 cup screws and M6 wizz nuts provided.
9. If carriers are to be fitted. See carrier instructions.

BOLT KIT BK3800 ML TRITON REAR BAR

QUANTITY	DESCRIPTION
8	BOLT M12 X 35 X 1.75
2	BOLT ON WIRE M12 X 35 X 1.75 300 MM WIRE
18	WASHER FLAT M12 X 30 HD
10	WASHER SPRING M12
10	NUT M12 X 1.75
1	WIRE TRAILER 7 CORE 2000 MM LENGTH
10	WIRE CONNECTOR MALE
10	WIRE CONNECTOR FEMALE

